

more "dummy" voltage sources to act as current measurement points in the SPICE analysis (all set to 0 volts).

