

HOW TO CHECK SUPER HEAT AIR CONDITIONING / HEAT PUMPS

R-22

Take suction
temperature
10" - 12" from
compressor

58° F

Convert suction
pressure to
temperature

38° F

20° F

(See Pressure Temp Chart) ->

(65 PSIG = 38°)

SUPER HEAT